

DCH DVR 6400 and DCH 6200 Installation Setup Using RCA (Audio & Video) Cable

REMEMBER: With this setup, your TV must be set to whichever VIDEO INPUT you connected the video cable into. You can change this on your TV remote or main menu. Examples of the input channel are: Input (1 or 2), Source, Game or Video (1 or 2). Once you have the TV on the correct video setting, you can change the cable station on the digital box using our provided remote.

